

# **ProfiNet / ProfiBus**

## **Interfaces**

**TRANSLATION OF THE GERMAN ORIGINAL MANUAL**

Version	Modification
10	New Data set for the complete axis status inquiry (chap 8.2.) Lis of Parameters

© 2015

All rights with:

Phytron GmbH

Industriestraße 12

82194 Gröbenzell, Germany

Tel.: +49(0)8142/503-0

Fax: +49(0)8142/503-190

In this manual you will find the feature descriptions and programming a controller for positioning of a stepper motor.

This manual is supplementary to the “*phyLOGIC*™-Command References” and “Principles of Positioning”.

Every possible care has been taken to ensure the accuracy of this technical manual. All information contained in this manual is correct to the best of our knowledge and belief but cannot be guaranteed. Furthermore we reserve the right to make improvements and enhancements to the manual and / or the devices described herein without prior notification.

We appreciate suggestions and criticisms for further improvement.

Email address: [doku@phytron.de](mailto:doku@phytron.de)

Questions about the use of the product described in the manual that you cannot find answered here, please contact your representative of phytron (<http://www.phytron.eu/>) in your local agencies.

## 1 Legal information



### This manual:

*Read this manual very carefully before mounting, installing and operating the device and if necessary further manuals related to this manual.*

- Please pay special attention to instructions that are marked as follows:

	<b>DANGER – Serious injury!</b>	<i>Indicates a high risk of serious injury or death!</i>
	<b>DANGER – Serious injury from electric shock!</b>	<i>Indicates a high risk of serious injury or death from electric shock!</i>
	<b>WARNING – Serious injury possible!</b>	<i>Indicates a possible risk of serious injury or death!</i>
	<b>WARNING – Serious injury from electric shock!</b>	<i>Indicates a possible risk of serious injury or death from electric shock!</i>
	<b>CAUTION – Possible injury!</b>	<i>Indicates a possible risk of personal injury.</i>
	<b>CAUTION – Possible damage!</b>	<i>Indicates a possible risk of damage to equipment.</i>
	<b>CAUTION – Possible damage due to ESD!</b>	<i>Refers to a possible risk of equipment damage from electrostatic discharge.</i>
	<b>”Any heading“</b>	<i>Refers to an important paragraph in the manual.</i>

### Safety Instructions

**i** **CAUTION – Possible damage!**  
*Malfunctions are possible while programming the instruction codes – e.g. sudden running of a connected motor, braking etc.*

- Please test the program flow step by step.

**i** **CAUTION – Possible damage!**  
*For each application, the functional reliability of software products by external factors such as voltage differences or hardware failure, etc. is affected.*

- To prevent damage due to system error, the user should take appropriate safety measures. These include back-up and shut-down mechanisms.

**i** **CAUTION – Possible damage!**  
*Each end user system is customised and differs from the testing platform. Therefore the user or application designer is responsible for verifying and validating the suitability of the application.*

- The suitability of the device's use must be tested and validated.

**i** **CAUTION – Possible damage!**  
*Some modules are set to a default value on delivery. So, e.g., the motor current must be set to the corresponding value (see the motor data from the motor manufacturer). Connected components like motors can be damaged by incorrectly set values.*

- Please check before starting, if the parameters are correct.

## 2 Contents

<b>1 Legal information .....</b>	<b>3</b>
<b>2 Contents.....</b>	<b>5</b>
<b>3 Introduction .....</b>	<b>6</b>
<b>4 Declaration of Incorporation .....</b>	<b>8</b>
<b>5 Conditions.....</b>	<b>9</b>
<b>6 Configuration of the <i>phy</i>MOTION™ via SIMATIC Manager (Example) .....</b>	<b>10</b>
<b>7 Download from the ftp Server .....</b>	<b>11</b>
7.1 Firmware Download .....	11
7.2 Download of <i>phy</i> LOGIC™ Programs (Scripts) .....	12
<b>8 Interface Assignment.....</b>	<b>13</b>
8.1 Master Unit (CPU).....	13
8.1.1 Data Set (Commands) (8 bytes).....	13
8.1.2 Status Code (CPU).....	15
8.1.3 Error Code (CPU).....	15
8.2 Axes Modules I1AM01 and I4XM01 .....	16
8.2.1 Status Code (Axes) .....	21
8.2.2 Error Code (Axes) .....	22
8.3 Digital I/O Modules (DIOM) .....	23
8.3.1 Status Code (DIOM).....	24
8.3.2 Error Code (DIOM) .....	24
8.4 Analogue Output Module (AIOM or AOM).....	25
8.5 Analogue Input Module (AIOM or AIM) .....	26
8.5.1 Status Code (AIOM) .....	27
8.5.2 Error Code AIOM.....	27
<b>9 List of Parameters .....</b>	<b>28</b>
<b>10 Warranty, Disclaimer and Registered Trademarks .....</b>	<b>38</b>
10.1 Disclaimer.....	38
10.2 Warranty.....	38
10.3 Registered Trademarks.....	38
<b>11 Index.....</b>	<b>39</b>

## 3 Introduction

*phyLOGIC*<sup>™</sup> is the programming language to communicate with phytron programmable logic controllers like the MCC-Series or our *phyMOTION*<sup>™</sup>.

*phyLOGIC*<sup>™</sup> commands can easily be sent to the controller with phytron's programming software (*phyLOGIC*<sup>™</sup> Toolbox) via USB, embedded into other protocols like Ethernet or into interface protocols like ProfiBus / ProfiNet.

You can parameterise your commands (e.g. a driving command) per axis either just the first time you set up your system, or adjust the parameters temporarily before sending a driving command.


Example: For "relative run" you can set: step resolution (P45), run current (P41), run frequency (P14), start stop frequency (P04), ramp (P15), recovery time (P16), boost (P17), boost current (P42), current hold time (P43), etc.

Use this illustration to find the adequate manual for your programming task:

### Host interface (ProfiNet/ProfiBus):



Please refer to manual:  
„ProfiNet / ProfiBus interfaces“




Host interface (ProfiNet/ProfiBus) Protocol

### Stepper controller programming:




Please refer to manual:  
„*phyLOGIC*<sup>™</sup>–Command references“



### Principle of positioning:



Please refer to manual:  
„Principles of positioning“



Each of our programmable controllers comes along with pre set parameters (default values), which are automatically loaded into the temporary memory of each axis while starting the device. These parameters can be changed during your program is executed to optimise your motion tasks at any time.

If you want your controller to wake up with a new set of parameters, you have to explicitly store them in the non volatile storage of the main CPU unit by using a certain command.

## 4 Declaration of Incorporation



### Declaration of Conformity according to EC directive 2004/108/EC (EMC-Directive)

**Name and address of the manufacturer:**

Phytron-Elektronik GmbH,  
Industriestr. 12  
82194 Gröbenzell

We declare that the following product is in conformity with the EC Directives 2004/108/EC relating to EMC.

**Product denomination**

Part-No.	Title	
10015035	MCM01.1	Main Controller Module
10015036	CANS01.1	CAN Communication Sub Module
10015037	ETHS01.1	Ethernet Communication Sub Module
10015039	PBS01.1	Profibus Communication Sub Module
10015040	PNS01.1	ProfiNet Communication Sub Module
10015041	RSS01.1	RS485/RS232 Communication Sub Module

From serial number 1205xxxxx

**Applied harmonized standards**

- EN 61000-6-1: 2007-01 Electromagnetic Compatibility (EMC) - Immunity for residential, commercial and light-industrial environmental
- EN 61000-6-2: 2005-08 Electromagnetic compatibility (EMC) - Immunity for industrial environments
- EN 61000-6-3: 2007-01 Electromagnetic compatibility (EMC) - Emission standard for residential, commercial and light-industrial environments
- EN 61000-6-4: 2007-01 Electromagnetic compatibility (EMC) - Emission standard for industrial environments

**Comment:**

This declaration of conformity is valid only if the device is built in a suitable casing e.g. phyMOTION-6SL-MR-s.

Gröbenzell, 2012-05-10

  
Johannes Schmid  
Technical Director

AP QS-0672-3  
CE 7035 Rev. 1

Phytron-Elektronik GmbH

Industriestr. 12 - 82194 Gröbenzell  
Postfach 1255 - 82180 Gröbenzell  
T +49-8142-503-0 F +49-8142-503-190  
E info@phytron.de W www.phytron.de

Geschäftsführung Birgit Hartmann  
Reg.-Gericht München - HRB 44 426  
USt-Ident.-Nr. DE 128 242 222  
Steuernummer 117-135-10027

Genossenschaftsbank - Kto. 96610 - BLZ 70169464  
IBAN DE 6770 1694 6400 0009 6610 - BIC GENODEF1M07  
Sparkasse Fürstenfeldbruck - Kto. 1801265 - BLZ 70053070  
Oberbank München - Kto. 1041021021 - BLZ 70120700  
Volksbank Fürstenfeldbruck - Kto. 712531 - BLZ 70163370  
Postbank München - Kto. 0286001800 - BLZ 70010080



## 5 Conditions

---

- You have an S7 station, consisting of a power supply module and a CPU and configured.
- The PG is connected to the PROFINET I/O.
- The *phy***MOTION**<sup>TM</sup> controller is connected to the superior main station via ProfiNet interface.

## 6 Configuration of the *phyMOTION*<sup>TM</sup> via SIMATIC Manager (Example)

- Install the GSD data file which comes with your delivery on your PC.
- Start the SIMATIC manager and open the project that you have created.
- Add the *phyMOTION*<sup>TM</sup> rack from the hardware catalogue (HW Config) with drag & drop.
- Drag the individual modules according to the module assembly in the housing (from left to right) from the hardware catalogue *phyMOTION*<sup>TM</sup>.
- **Important:** The POWM01 and POWM02 modules are ignored because they are not addressed!




Fig.1 Configuration of the *phyMOTION*<sup>TM</sup> with HW Config

Save and compile the hardware configuration with *station > save and compile*.

## 7 Download from the ftp Server

The phytron PNS01 sub module contains an internal ftp server. This ftp server can be used for updating the firmware of every active *phyMOTION*<sup>TM</sup> module like MCM01, MCM02, I1AM01, DIOM01, etc.

You can also transmit *phyLOGIC*<sup>TM</sup> programs (scripts) via the ftp server to the *phyMOTION*<sup>TM</sup>.

### 7.1 Firmware Download

The firmware of the modules is developed and delivered by phytron.

To update the firmware of the individual modules proceed as follows:

1. Open the Windows Explorer and enter in the command line:  
`//ftp <IP-address of the phyMOTIONTM>`  
 The IP address is assigned by the PLC after the initialisation.
2. Enter in the ftp client window:  
 User name: Phytron  
 Password: Phytron  
 Confirm with the button LOGIN.
3. A window with a list of files stored on the ftp server is opened, e.g.

MCM0x.phyMotion:    Firmware file for the master (MCM0x)

I1AM01.phyMotion:    Firmware file for the 1 axis drive (I1AM01)

DIOM01.phyMotion:    Firmware file for the digital I/O module (DIOM01)

4. To a file, it has to be highlighted. Then press the DELETE button.
5. Open the folder containing the new firmware in a second window.  
 Save the new firmware files by drag and drop on the ftp server.

**IMPORTANT: The firmware files must be deleted before a restoring, because they can't be overwritten on the ftp server!**

**If a new firmware is loaded to the ftp server, the “new” firmware is always transmitted to all modules of the same type.**

6. First, after a restart or reset the firmware version no. on the ftp server is compared with the version no of the MCM module.  
 If they differ, the firmware of the MCM module is automatically updated with the firmware of the ftp server.
7. If they don't differ, no firmware will be updated. The files remain even after successful ftp download on the ftp server.

Leave the current files on the ftp server, so a module recently inserted into the *phyMOTION*<sup>TM</sup> is automatically updated to the latest firmware status, which is stored on the ftp server.

**IMPORTANT:** It is only checked whether the update version of the ftp server differs from the version of the module. Therefore, you can set the firmware back to an older version by replacing the file on the ftp server with the older firmware file.

### 7.2 Download of *phyLOGIC*<sup>TM</sup> Programs (Scripts)

---

- Write a script in *phyLOGIC*<sup>TM</sup>, then save it with the name <no>.mpr. There are possible more than 1 to 255 as <nr> program name.
- Open the Windows Explorer and enter in the command line:  
//ftp <IP address of the *phyMOTION*<sup>TM</sup>>  
The IP address is assigned by the PLC after the initialisation.
- Enter in the ftp client window:  
User name: Phytron  
Password: Phytron  
Confirm with the button LOGIN.
- Open the folder in a second window where the sequential programs for the *phyMOTION*<sup>TM</sup> are stored, e.g.:  
  
1.mpr      sequential program 1 for stepper motor controller  
  
2.mpr      sequential program 2 for stepper motor controller  
  
255.mpr    sequential program 255 for stepper motor controller
- Save the required sequential programs by drag and drop on the ftp server
- After restart or reset all „mpr“-files are transmitted from the ftp server to the MCM module and then are automatically deleted on the ftp server.

## 8 Interface Assignment

*phyLOGIC*<sup>™</sup> commands usually contain the module address (e.g. when you are using *phyLOGIC*<sup>™</sup> Toolbox).

As you can see in the screenshot of the HW Config (Fig.1) every *phyMOTION*<sup>™</sup> module card already is addressed in the Profinet system. Once addressed commands can be sent to every single module card. In the following section the instruction set per module type is given referring to the *phyLOGIC*<sup>™</sup> command reference manual

### 8.1 Master Unit (CPU)

#### 8.1.1 Data Set (Commands) (8 bytes)

	Function of commands (8 bytes)	Byte								According to <i>phyLOGIC</i> <sup>™</sup> command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	command	chap.
Send	Read CPU status	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	ST	6.17
	Status and Error Reset	00 <sub>H</sub>	01 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	STC	6.17
	Controller Reset	01 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	CR	6.3
	Save controller's parameters	02 <sub>H</sub>	01 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	SA	6.14
	Terminates the save of the controller's parameters <sup>1)</sup>	02 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	–	
	Start program script	03 <sub>H</sub>	01 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	XX <sub>H</sub> <sup>2)</sup>	QPname A	6.14
	Stop program script	03 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	QPE	6.14
	Emergency stop of all axes and outputs are set to zero	04 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	–	
	Read register										
	signed long	40 <sub>H</sub>	10 <sub>H</sub>	Register no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	RnnR	6.15
	float	40 <sub>H</sub>	40 <sub>H</sub>	Register no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	RnnR	6.15

	Function of commands (8 bytes)	Byte								According to <i>phyLOGIC</i> <sup>TM</sup> command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	command	chap.
	Write register										
	signed long	41 <sub>H</sub>	10 <sub>H</sub>	Register no	Register value					Rnn Svalue	6.15
	float	41 <sub>H</sub>	40 <sub>H</sub>	Register no	Register value					RnnS value	6.15

- 1) The command 0201<sub>H</sub> sets the flag 'Save parameters'. This flag must be reset before resaving the parameters. The command 0200<sub>H</sub> resets this flag.
- 2) XX<sub>H</sub> has to be replaced by the script number which should be started. It must be registered in hexadecimal code. E.g. code 0A<sub>H</sub> starts script no. 10.mpr (see chap. 6.3).

Function		Byte							
		1	2	3	4	5	6	7	8
Response	Controller Reset status	00 <sub>H</sub>	Error code	Status		00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>
	Read master status	01 <sub>H</sub>	Error code	Status		00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>
	Save controller's parameters	02 <sub>H</sub>	Error code	Status		00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>
	Start / stop program	03 <sub>H</sub>	Error code	Status		00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>
	Emergency stop program	04 <sub>H</sub>	Error code	Status		00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>
	Read register								
	signed long	40 <sub>H</sub>	10 <sub>H</sub>	Register no		Register value			
	float	40 <sub>H</sub>	40 <sub>H</sub>	Register no		Register value			
	Write register								
	signed long	41 <sub>H</sub>	10 <sub>H</sub>	Register no		Register value			
	float	41 <sub>H</sub>	40 <sub>H</sub>	Register no		Register value			

### 8.1.2 Status Code (CPU)

Status (2 bytes)	Meaning
0001 <sub>H</sub>	Command error
0002 <sub>H</sub>	Range value error
0004 <sub>H</sub>	Checksum error (CRC)
0008 <sub>H</sub>	ADDR error (card could not be addressed)
0010 <sub>H</sub>	Timeout error on bus
0020 <sub>H</sub>	Bad value error
0040 <sub>H</sub>	Interface error (frame)
0080 <sub>H</sub>	Software error
0100 <sub>H</sub>	Internal program is running
0200 <sub>H</sub>	Forced switch over to remote via PC
1000 <sub>H</sub>	Programming error: internal program
2000 <sub>H</sub>	Flag 'Parameters are changed'; this flag is reset by the command 0201 <sub>H</sub> .
4000 <sub>H</sub>	Input inquiry active (wait for input status)
8000 <sub>H</sub>	Remote/Local switch on Remote

### 8.1.3 Error Code (CPU)

Error (1 byte)	Meaning
00 <sub>H</sub>	OK
0m <sub>H</sub>	Error in module no. m m: module number 1 to 14 <sub>H</sub> (module 1 to 20 in one sub rack)

## 8.2 Axes Modules I1AM01 and I4XM01

Important: Byte '3' (axis no.) differs for the two axis modules:

I1AM01: axis no. = 00<sub>H</sub>

I4XM01: axis no. = 00<sub>H</sub> to 03<sub>H</sub>

Function		Byte								Acc. to <i>phyLOGIC</i> <sup>TM</sup> command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	command	chap.
Send	Axis status										
	Read	10 <sub>H</sub>	00 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	SEm.a	6.17
	Error reset	10 <sub>H</sub>	01 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	n/a	
	Read the complete status	10 <sub>H</sub>	02 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	SEm.a	6.17
	Axis instruction Reset	11 <sub>H</sub>	00 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	–	
	Axis stop										
	normal	12 <sub>H</sub>	00 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aS	6.25
	with emergency stop ramp	12 <sub>H</sub>	01 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aSN	6.25
	Reference run										
	– direction	13 <sub>H</sub>	00 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR–	6.25
	+ direction	13 <sub>H</sub>	01 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR+	6.25
	CENTER switch via – direction	13 <sub>H</sub>	02 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR–C	6.25
	CENTER switch via + direction	13 <sub>H</sub>	03 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR+C	6.25
	– direction with encoder track zero	13 <sub>H</sub>	04 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR–^I	6.25
	+ direction with encoder track zero	13 <sub>H</sub>	05 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR+^I	6.25



Function		Byte								Acc. to <i>phyLOGIC</i> ™ command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	command	chap.
Send	CENTER switch via – direction with encoder track zero	13 <sub>H</sub>	06 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR-C^I	6.25
	CENTER switch via + direction with encoder track zero	13 <sub>H</sub>	07 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR+C^I	6.25
	only pulse zero in – direction	13 <sub>H</sub>	08 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR-I	6.25
	only pulse zero in + direction	13 <sub>H</sub>	09 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aR+I	6.25
	Centre to initiator OFF	13 <sub>H</sub>	0A <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aRC-	6.25
	Centre to initiator ON	13 <sub>H</sub>	0B <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aRC+	6.25
	Centre to initiator OFF with encoder track zero	13 <sub>H</sub>	0C <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aRC-^I	6.25
	Centre to initiator ON with encoder track zero	13 <sub>H</sub>	0D <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aRC+^I	6.25
	Centre only in + direction	13 <sub>H</sub>	0E <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aRCW	6.25
	Centre only in – direction	13 <sub>H</sub>	0F <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aRCCW	6.25
	Free running										
	– direction	14 <sub>H</sub>	00 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aL– (m.aLr)	6.25
	+ direction	14 <sub>H</sub>	01 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aL+ (m.aLr)	6.25

Function		Byte								Acc. to <i>phyLOGIC</i> <sup>TM</sup> command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	command	chap.
Send	Relative Positioning with parameter P14	15 <sub>H</sub>	10 <sub>H</sub>	Axis no.	00 <sub>H</sub>	distance signed long				m.arvalue	6.25
	P14	15 <sub>H</sub>	40 <sub>H</sub>	Axis no.	00 <sub>H</sub>	distance float				m.arvalue	6.25
	P4	15 <sub>H</sub>	11 <sub>H</sub>	Axis no.	00 <sub>H</sub>	distance signed long				m.arvalue	6.25
	P4	15 <sub>H</sub>	41 <sub>H</sub>	Axis no.	00 <sub>H</sub>	distance float				m.arvalue	6.25
	Absolute Positioning with parameter P14	16 <sub>H</sub>	10 <sub>H</sub>	Axis no.	00 <sub>H</sub>	position signed long				m.aArvalue	6.25
	P14	16 <sub>H</sub>	40 <sub>H</sub>	Axis no.	00 <sub>H</sub>	position float				m.aArvalue	6.25
Send	P4	16 <sub>H</sub>	11 <sub>H</sub>	Axis no.	00 <sub>H</sub>	position signed long				m.aArvalue	6.25
	P4	16 <sub>H</sub>	41 <sub>H</sub>	Axis no.	00 <sub>H</sub>	position float				m.aArvalue	6.25
	Deactivate axis	17 <sub>H</sub>	00 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aMD	6.25
	Activate axis	17 <sub>H</sub>	01 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aMA	6.25
Send	Reset power stage	18 <sub>H</sub>	00 <sub>H</sub>	Axis no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aC	6.25

Function		Byte								Acc. to <i>phyLOGIC</i> ™ command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	command	chap.
Write parameters	signed long	19 <sub>H</sub>	10 <sub>H</sub>	Axis no.	Para- meter no.	Parameter value				m.aPmm Svalue	6.25
	float	19 <sub>H</sub>	40 <sub>H</sub>	Axis no.	Para- meter no.	Parameter value				m.aPmm Svalue	6.25
Read parameters	signed long	1A <sub>H</sub>	10 <sub>H</sub>	Axis no.	Para- meter no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aPmmR	6.25
	float	1A <sub>H</sub>	40 <sub>H</sub>	Axis no.	Para- meter no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	m.aPmmR	6.25

Function		Byte							
		1	2	3	4	5	6	7	8
Response	Read axis status	10 <sub>H</sub>	Error code	Status		Current position			
	Read the complete axis status	10 <sub>H</sub>	Error code	Status		Status 32 bit			
	Axis instruction Reset	11 <sub>H</sub>	Error code	Status		Current position			
	Axis stop	12 <sub>H</sub>	Error code	Status		Current position			
	Reference running	13 <sub>H</sub>	Error code	Status		Current position			
	Free running	14 <sub>H</sub>	Error code	Status		Current position			
	Relative Positioning	15 <sub>H</sub>	Error code	Status		Current position			
	Absolute Positioning	16 <sub>H</sub>	Error code	Status		Current position			
	Deactivate axis/ Activate axis	17 <sub>H</sub>	Error code	Status		Current position			
	Reset power stage	18 <sub>H</sub>	Error code	Status		Current position			
	Write parameters	19 <sub>H</sub>	Data type	Axis no.	Parameter no.	Parameter value			
	Read parameters	1A <sub>H</sub>	Data type	Axis no.	Parameter no.	Parameter value			

## 8.2.1 Status Code (Axes)

Status (2 bytes)	Meaning
0001 <sub>H</sub>	Busy (motor is running)
0002 <sub>H</sub>	Not now (command cannot be executed because the motor is running)
0004 <sub>H</sub>	Wait for SYNC (only ProfiNet)
0008 <sub>H</sub>	Reference run successful
0010 <sub>H</sub>	Limit switch '+' is active
0020 <sub>H</sub>	Limit switch '-' is active
0040 <sub>H</sub>	Limit switch 'center' is active
0080 <sub>H</sub>	Software switch '+' responded
0100 <sub>H</sub>	Software switch '-' responded
0200 <sub>H</sub>	Power stage is busy
0400 <sub>H</sub>	Axis is in the ramp
0800 <sub>H</sub>	Internal error
1000 <sub>H</sub>	Limit switch error while positioning
2000 <sub>H</sub>	Power stage error (short circuit, under voltage)
4000 <sub>H</sub>	SFI error
8000 <sub>H</sub>	Encoder error
10000 <sub>H</sub>	Axis is running
20000 <sub>H</sub>	Axis is in recovery time (s. parameter P13 or P16)
40000 <sub>H</sub>	Axis is in stop current delay time (parameter P43)
80000 <sub>H</sub>	Axis is in position
100000 <sub>H</sub>	Axis APS is ready
200000 <sub>H</sub>	Axis is positioning mode

Status (2 bytes)	Meaning
400000 <sub>H</sub>	Axis is in free running mode
800000 <sub>H</sub>	Axis multi F run
1000000 <sub>H</sub>	Axis SYNC allowed

### 8.2.2 Error Code (Axes)

---

Error (1 byte)	Meaning
00 <sub>H</sub>	OK
01 <sub>H</sub>	Data error
02 <sub>H</sub>	Motor temperature warning
04 <sub>H</sub>	Motor shut-off temperature is reached
08 <sub>H</sub>	Power stage temperature > 85°C
10 <sub>H</sub>	Error limit switch
20 <sub>H</sub>	Error power stage
40 <sub>H</sub>	SFI step failure
80 <sub>H</sub>	Error encoder

### 8.3 Digital I/O Modules (DIOM)

Function		Byte								Acc. to <i>phyLOGIC</i> <sup>TM</sup> command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	command	chap.
Send	Read I/O status	20 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	<b>AZ</b> <sub>n.a</sub> <b>AG</b> 1R <b>EZ</b> <sub>n.a</sub> <b>EG</b> 1R	6.3 6.3 6.5 6.5
	Reset I/O Status	20 <sub>H</sub>	01 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	<b>SI</b> 0mC	6.20
	Read input status and set output status	21 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Output		-	-

Function		Byte							
		1	2	3	4	5	6	7	8
Response	Read I/O status	20 <sub>H</sub>	Error code	Sta tus	00 <sub>H</sub>	Input		Output	
	Read input status and set output status	21 <sub>H</sub>	Error code	Sta tus	00 <sub>H</sub>	Input		Output	

### 8.3.1 Status Code (DIOM)

---

Status (1 byte)	Meaning
01 <sub>H</sub>	Error
10 <sub>H</sub>	Interrupt 1
20 <sub>H</sub>	Interrupt 2

### 8.3.2 Error Code (DIOM)

---

Error (1 byte)	Meaning
00 <sub>H</sub>	OK
01 <sub>H</sub>	unknown Instruction
02 <sub>H</sub>	incorrect instruction
04 <sub>H</sub>	incorrect data
10 <sub>H</sub>	Short circuit at output
20 <sub>H</sub>	24 V electrically isolated is missed (no 24 V applied)



## 8.4 Analogue Output Module (AIOM or AOM)

Function		Byte								Acc. to phyLOGIC™ command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	Command	chap.
Send	Read analogue output channel	50 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	cha nnel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	<b>AZn.a</b> <b>AG1R</b> <b>EZn.a</b> <b>EG1R</b>	6.2 6.2 6.5 6.5
	Analogue I/O error Reset	50 <sub>H</sub>	01 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	<b>SI0mC</b>	6.15
	Set output channel	51 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	cha nnel no.	00 <sub>H</sub>	00 <sub>H</sub>	Analogue value		-	-
	Read output channel configuration	52 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	cha nnel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>		
	Write output channel configuration	53 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	cha nnel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Fun ctio n		

Function		Byte							
		1	2	3	4	5	6	7	8
Response	Read analogue output channel	50 <sub>H</sub>	Error code	Sta- tus	cha nnel no	00 <sub>H</sub>	00 <sub>H</sub>	Analogue value	
	Set output channel	51 <sub>H</sub>	Error code	Sta- tus	cha nnel no	00 <sub>H</sub>	00 <sub>H</sub>	Analogue value	
	Read output channel configuration	52 <sub>H</sub>	Error code	Sta- tus	cha nnel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Fun ctio n
	Write output channel configuration	53 <sub>H</sub>	Error code	Sta- tus	cha nnel no.	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Fun ctio n

## 8.5 Analogue Input Module (AIOM or AIM)

Function		Byte								Acc. to <i>phyLOGIC</i> ™ command (refer to the command reference manual)	
		1	2	3	4	5	6	7	8	Command	chap.
Send	Read analogue input channel	60 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Channel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	<b>AZn.a</b> <b>AG1R</b> <b>EZn.a</b> <b>EG1R</b>	6.2 6.2 6.5 6.5
	Analogue I/O error Reset	60 <sub>H</sub>	01 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	<b>SI0mC</b>	6.15
	Read input channel configuration	62 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Channel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>		
	Write input channel configuration	63 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Channel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Function		

Function		Byte							
		1	2	3	4	5	6	7	8
Response	Read analogue input channel	60 <sub>H</sub>	Error code	I/O status	Channel no	00 <sub>H</sub>	00 <sub>H</sub>	Analogue value	
	Read input channel configuration	62 <sub>H</sub>	Error code	I/O status	Channel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Function
	Write input channel configuration	63 <sub>H</sub>	Error code	I/O status	Channel no	00 <sub>H</sub>	00 <sub>H</sub>	00 <sub>H</sub>	Function

### 8.5.1 Status Code (AIOM)

Status (1 byte)	Meaning
01 <sub>H</sub>	Error
10 <sub>H</sub>	Interrupt 1
20 <sub>H</sub>	Interrupt 2

### 8.5.2 Error Code AIOM

Error (1 byte)	Meaning
00 <sub>H</sub>	Module OK
01 <sub>H</sub>	unknown Instruction
02 <sub>H</sub>	incorrect instruction
04 <sub>H</sub>	incorrect data
10 <sub>H</sub>	DAC error
20 <sub>H</sub>	24 V electrically isolated is missed (no 24 V applied)

## 9 List of Parameters

No.	Meaning	Default
<b>P01</b>	<p>Type of movement (free run, relative / absolute, reference run)</p> <p>0 = Rotational movement (ignoring limit switches)</p> <p>1 = Hardware limit switches are monitored for XY tables or other linear systems, 2 limit switches: Mechanical zero and limit direction – Limit direction +</p> <p>2 = Software limit switches are monitored</p> <p>3 = Hardware and software limit switches are monitored</p>	0
<b>P02</b>	<p>Measuring units of movement: only used for displaying</p> <p>1 = step</p> <p>2 = mm</p> <p>3 = inch</p> <p>4 = degree</p>	1
<b>P03</b>	<p>Conversion factor for the thread</p> <p>1 step corresponds to ...</p> <p>If P03 = 1 (steps) the conversion factor is 1.</p> <p>Computing the conversion factor:</p> $\text{Conversion factor} = \frac{\text{Thread}}{\text{Number of steps per revolution}}$ <p><u>Example:</u></p> <p>4 mm thread pitch</p> <p>200-step motor = 400 steps/rev. in the half step mode</p> $\text{Conversion factor} = \frac{4}{400} = 0.01$	1
<b>P04</b>	<p>Start/stop frequency</p> <p>The start/stop frequency is the maximum frequency to start or stop the motor without ramp. At higher frequencies, step losses or motor stop would be the result of a start or stop without ramp. The start/stop frequency depends on various factors: type of motor, load, mechanical system, power stage.</p> <p>The frequency is programmed in Hz.</p>	400

No.	Meaning	Default
<b>P05</b> <b>P06</b>	not used	
<b>P07</b>	Emergency stop ramp Input for I1AM0x: in 4000 Hz/s steps I4XM01: in 1 Hz/s steps	100 000
<b>P08</b>	$f_{\max}$ MØP (mechanical zero point) Run frequency during initializing (referencing) Enter in Hz (integer value) I1AM0x: 40 000 maximum I4XM01: 4 000 000 maximum	4000
<b>P09</b>	Ramp MØP Ramp during initializing, associated to parameter P08 Input for I1AM0x: in 4000 Hz/s steps I4XM01: in 1 Hz/s steps	4000
<b>P10</b>	$f_{\min}$ MØP Run frequency for leaving the limit switch range Enter in Hz	400
<b>P11</b>	MØP offset for limit switch direction + (away from "LIMIT+" switch, towards "LIMIT-" switch) Distance between reference point MØP and limit switch activation Unit: is defined in parameter P02 P11 ≥ 0	0
<b>P12</b>	MØP offset for limit switch direction – (away from "LIMIT-" switch, towards "LIMIT+" switch) Distance between reference point MØP and limit switch activation Unit: is defined in parameter P02 P12 ≥ 0	0

No.	Meaning	Default
<b>P13</b>	Recovery time MØP Time lapse during initialization Enter in msec	20
<b>P14</b>	$f_{\max}$ Run frequency during program operation Enter in Hz (integer value) I1AM0x: 40 000 maximum I4XM01: 4 000 000 maximum	4000
<b>P15</b>	Ramp for run frequency (P14) Input for I1AM0x: in 4000 Hz/s steps I4XM01: in 1 Hz/s steps	4000
<b>P16</b>	Recovery time position Time lapse after positioning Input in msec	20
<b>P17</b>	Boost (current is defined in P42) 0 = off 1 = on during motor run 2 = on during acceleration and deceleration ramp <u>Remarks:</u> The boost current is set in parameter P42 for internal power stages. You can select with parameter P17 in which situation the controller switches to boost current. P17 = 1 means, the boost current always is switched on during motor run. During motor standstill the controller switches to stop current.	0
<b>P18</b>	Internally used for linear interpolation	
<b>P19</b>	Encoder deviation MØP counter	
<b>P20</b>	Mechanical zero counter This counter contains the number of steps referred to the mechanical zero (MØP). If the axis reaches the MØP, P20 will be set to zero.	0

No.	Meaning	Default
<b>P21</b>	<p>Absolute counter</p> <p>Encoder, multi turn and also for single turn.</p> <p>The value of P22 is extended to P21 by software. The encoder counters have a fixed resolution, e.g. 10 bit (for single-turn encoders: the resolution is bits per turn), then the read value repeats. A saw tooth profile of the the numerical values is produced during a continuous motor running. This course is "straightened" by software. P20 and P21 will be scaled to the same value per revolution by P3 and P39 and are therefore directly comparable, see P36.</p>	0
<b>P22</b>	<p>Encoder counter</p> <p>Indicates the true absolute encoder position.</p> <p>Is only set for A/B encoders to zero (after reset), the absolute encoder remains the value.</p>	0
<b>P23</b>	<p>Software Limit Switch (Axial limitation pos. direction +)</p> <p>If the distance is reached, the run in + direction is aborted.</p> <p>0 = no limitation</p>	0
<b>P24</b>	<p>Software Limit Switch (Axial limitation neg. direction –)</p> <p>If the distance is reached, the run in – direction is aborted.</p> <p>0 = no limitation</p>	0
<b>P25</b>	<p>Compensation for play</p> <p>Indicates the distance, the target position in the selected direction is passed over and afterwards is started in reverse direction.</p> <p>0 = no compensation for play</p>	0

No.	Meaning	Default																																				
P26	<p>The data transfer rate is set by P26 (<b>ONLY</b> for SSI encoder), by which the encoder is read. The transfer rate is dependent on the length of the cable by which the encoder is connected to the device. The shorter the cable, the encoder can more quickly be read.</p> <p>Data transfer rate 1 to 10 (= 100 to 1000 kHz)</p> <p>1 = 100 kHz 2 = 200 kHz 3 = 300 kHz 4 = 400 kHz 5 = 500 kHz 6 = 600 kHz 7 = 700 kHz 8 = 800 kHz 9 = 900 kHz 10 = 1000 kHz</p>	1																																				
P27	<p>Limit switch type</p> <p>NCC: normally closed contact</p> <p>NOC: normally open contact</p> <table><tr><td></td><td>LIMIT–</td><td>Center/Ref</td><td>LIMIT+</td></tr><tr><td>0</td><td>NCC</td><td>NCC</td><td>NCC</td></tr><tr><td>1</td><td>NCC</td><td>NCC</td><td>NOC</td></tr><tr><td>2</td><td>NOC</td><td>NCC</td><td>NCC</td></tr><tr><td>3</td><td>NOC</td><td>NCC</td><td>NOC</td></tr><tr><td>4</td><td>NCC</td><td>NOC</td><td>NCC</td></tr><tr><td>5</td><td>NCC</td><td>NOC</td><td>NOC</td></tr><tr><td>6</td><td>NOC</td><td>NOC</td><td>NCC</td></tr><tr><td>7</td><td>NOC</td><td>NOC</td><td>NOC</td></tr></table>		LIMIT–	Center/Ref	LIMIT+	0	NCC	NCC	NCC	1	NCC	NCC	NOC	2	NOC	NCC	NCC	3	NOC	NCC	NOC	4	NCC	NOC	NCC	5	NCC	NOC	NOC	6	NOC	NOC	NCC	7	NOC	NOC	NOC	0
	LIMIT–	Center/Ref	LIMIT+																																			
0	NCC	NCC	NCC																																			
1	NCC	NCC	NOC																																			
2	NOC	NCC	NCC																																			
3	NOC	NCC	NOC																																			
4	NCC	NOC	NCC																																			
5	NCC	NOC	NOC																																			
6	NOC	NOC	NCC																																			
7	NOC	NOC	NOC																																			
P28	<p>Axis options</p> <p>0 = Power stage is deactivated after power on</p> <p>1 = Power stage is activated after power on</p>	0																																				
P29 not used																																						



No.	Meaning	Default																																												
P30	<p>For I4XM01 only!</p> <p>Frequency band setting</p> <p>0 = manual 1 = automatic</p> <p><u>Remark:</u> It is recommended to work with the automatic setting mode. For each run frequency (P14) and ramp (P15) the controller automatically selects suitable settings.</p>	1																																												
P31	<p>For I4XM01 only!</p> <p>Frequency and ramp predivider (only if P30 = 0, manual)</p> <p>This parameter changes the predivider which supplies the hardware (frequency generated) with a clock of 20 MHz derived.</p>	3																																												
	<table><tr><td>P31</td><td>Run frequency</td><td>resolution</td><td>predivider</td></tr><tr><td>0</td><td>1 Hz ... 8 kHz</td><td>1/8 Hz</td><td>2440</td></tr><tr><td>1</td><td>1 Hz ... 16 kHz</td><td>1/4 Hz</td><td>1220</td></tr><tr><td>2</td><td>1 Hz ... 32 kHz</td><td>1/2 Hz</td><td>609</td></tr><tr><td>3</td><td>1 Hz ... 65 kHz</td><td>1 Hz</td><td>304</td></tr><tr><td>4</td><td>2 Hz ... 130 kHz</td><td>2 Hz</td><td>152</td></tr><tr><td>5</td><td>4 Hz ... 260 kHz</td><td>4 Hz</td><td>75</td></tr><tr><td>6</td><td>8 Hz ... 520 kHz</td><td>8 Hz</td><td>37</td></tr><tr><td>7</td><td>16 Hz ... 1 MHz</td><td>16 Hz</td><td>18</td></tr><tr><td>8</td><td>32 Hz ... 2 MHz</td><td>32 Hz</td><td>9</td></tr><tr><td>9</td><td>64 Hz ... 4 MHz</td><td>64 Hz</td><td>4</td></tr></table> <p>The parameter can be used for individual settings when automatic frequency band setting for the specific application is not appropriate.</p>	P31	Run frequency	resolution	predivider	0	1 Hz ... 8 kHz	1/8 Hz	2440	1	1 Hz ... 16 kHz	1/4 Hz	1220	2	1 Hz ... 32 kHz	1/2 Hz	609	3	1 Hz ... 65 kHz	1 Hz	304	4	2 Hz ... 130 kHz	2 Hz	152	5	4 Hz ... 260 kHz	4 Hz	75	6	8 Hz ... 520 kHz	8 Hz	37	7	16 Hz ... 1 MHz	16 Hz	18	8	32 Hz ... 2 MHz	32 Hz	9	9	64 Hz ... 4 MHz	64 Hz	4	
P31	Run frequency	resolution	predivider																																											
0	1 Hz ... 8 kHz	1/8 Hz	2440																																											
1	1 Hz ... 16 kHz	1/4 Hz	1220																																											
2	1 Hz ... 32 kHz	1/2 Hz	609																																											
3	1 Hz ... 65 kHz	1 Hz	304																																											
4	2 Hz ... 130 kHz	2 Hz	152																																											
5	4 Hz ... 260 kHz	4 Hz	75																																											
6	8 Hz ... 520 kHz	8 Hz	37																																											
7	16 Hz ... 1 MHz	16 Hz	18																																											
8	32 Hz ... 2 MHz	32 Hz	9																																											
9	64 Hz ... 4 MHz	64 Hz	4																																											
P32	TBD	1																																												

No.	Meaning	Default
<b>P33</b>	TBD	1
<b>P34</b>	<p>Encoder type</p> <p>0 = no encoder  1 = incremental 5.0 V  2 = incremental 5.5 V  3 = serial interface SSI binary Code 5.0 V  4 = serial interface SSI binary Code 5.5 V  5 = serial interface SSI Gray Code 5.0 V  6 = serial interface SSI Gray Code 5.5 V  7 = EnDat 5 V  8 = EnDat 5.5 V  9 = resolver  10 = LVDT 4-wire  11 = LVDT 5/6-wire</p>	0
<b>P35</b>	<p>Encoder resolution for SSI and EnDat encoder</p> <p>Enter max. encoder resolution in Bit (max. 48 Bit)</p> <p>Special feature EnDat: if the parameter is set to zero, the controller uses the resolution which is read from the connected instrument.</p>	10
<b>P36</b>	<p>Encoder function</p> <p>This parameter specifies the use of P21 as a pure counter or whether its value is continuously compared with the value of the P20 counter, if the counter values vary too much, the motion is aborted with an error message.</p> <p>0 = counter  1 = counter+SFI</p>	0
<b>P37</b>	<p>Encoder tolerance for SFI</p> <p>Enter tolerance value for SFI evaluation</p> <p>Input: tolerance value for SFI-evaluation in the selected resolution (<math>P3 * P20</math>). If P21 is used for step failure indication the scale of the counter <math>P20 * P3</math> must be equal to the scale of the counter <math>P21 * P39</math> and P21 must be set to zero after initialization of the scaling (or can be set to the same value as P20).</p> <p>e.g. scaling to <math>360^\circ/\text{rev.}</math>: Motor 200 steps per revolution, 1/20 step, <math>\rightarrow P3 = 360 / 200 / 20 = 0.09</math>,  encoder 10 bit / rev. <math>\rightarrow P39 = 360 / 2^{10} = 0.3515625</math></p>	0

No.	Meaning	Default
<b>P38</b>	Encoder preferential direction of rotation 0 = + (positive) 1 = – (negative)	0
<b>P39</b>	Encoder conversion factor 1 increment corresponds to ... Computing the conversion factor: $\text{Conversion factor} = \frac{\text{Thread}}{\text{Encoder steps per revolution}}$	1
<b>P40</b>	Stop current in 0.01 A <sub>r.m.s.</sub> steps depending on the power stage  I1AM01: 0 to 250 (0 to 2.5 A <sub>r.m.s.</sub> ) I1AM02: 0 to 350 (0 to 3.5 A <sub>r.m.s.</sub> ) ZMX <sup>+</sup> : 0 to 630 (0 to 6.3 A <sub>r.m.s.</sub> ) MCD <sup>+</sup> : 0 to 63 (0 to 6.3 A <sub>r.m.s.</sub> ) APS: 0 to 350 (0 to 3.5 A <sub>r.m.s.</sub> ) MSX52: 0 to 280 (0 to 2.8 A <sub>r.m.s.</sub> ) MSX102: 0 to 560 (0 to 5.6 A <sub>r.m.s.</sub> ) MSX152: 0 to 840 (0 to 8.4 A <sub>r.m.s.</sub> )	2
<b>P41</b>	Run current in 0.01 A <sub>r.m.s.</sub> steps  I1AM01: 0 to 250 (0 to 2.5 A <sub>r.m.s.</sub> ) I1AM02: 0 to 350 (0 to 3.5 A <sub>r.m.s.</sub> ) ZMX <sup>+</sup> : 0 to 630 (0 to 6.3 A <sub>r.m.s.</sub> ) MCD <sup>+</sup> : 0 to 63 (0 to 6.3 A <sub>r.m.s.</sub> ) APS: 0 to 350 (0 to 3.5 A <sub>r.m.s.</sub> ) MSX52: 0 to 280 (0 to 2.8 A <sub>r.m.s.</sub> ) MSX102: 0 to 560 (0 to 5.6 A <sub>r.m.s.</sub> ) MSX152: 0 to 840 (0 to 8.4 A <sub>r.m.s.</sub> )	6
<b>P42</b>	Boost current in 0.01 A <sub>r.m.s.</sub> steps  I1AM01: 0 to 250 (0 to 2.5 A <sub>r.m.s.</sub> ) I1AM02: 0 to 350 (0 to 3.5 A <sub>r.m.s.</sub> ) ZMX <sup>+</sup> : 0 to 630 (0 to 6.3 A <sub>r.m.s.</sub> ) MCD <sup>+</sup> : 0 to 63 (0 to 6.3 A <sub>r.m.s.</sub> ) APS: 0 to 350 (0 to 3.5 A <sub>r.m.s.</sub> ) MSX52: 0 to 280 (0 to 2.8 A <sub>r.m.s.</sub> ) MSX102: 0 to 560 (0 to 5.6 A <sub>r.m.s.</sub> ) MSX152: 0 to 840 (0 to 8.4 A <sub>r.m.s.</sub> )	10

No.	Meaning	Default
<b>P43</b>	Current hold time in msec	20
<b>P44</b>	For I4XM01 only! Origin of the Control pulses for the axis 0 = 1:1 (Input=Output) 1 = from X 2 = from Y 3 = from Z 4 = from U 5 = from external	0
<b>P45</b>	Step resolution 1 to 512  <div> <div>0 = 1/1 step</div> <div>7 = 1/16 step</div> <div>1 = 1/2 step</div> <div>8 = 1/20 step</div> <div>2 = 1/2.5 step</div> <div>9 = 1/32 step</div> <div>3 = 1/4 step</div> <div>10 = 1/64 step</div> <div>4 = 1/5 step</div> <div>11 = 1/128 step</div> <div>5 = 1/8 step</div> <div>12 = 1/256 step</div> <div>6 = 1/10 step</div> <div>13 = 1/512 step (e.g. APS01)</div> </div> Important: for I1AM: step resolution from 1/1 to 1/128 step	3
<b>P46</b>	not used	
<b>P47</b>	not used	
<b>P48</b>	not used	
<b>P49</b>	Power stage temperature in 1/10 °C	(read only)
<b>P50</b>	Divider for Control pulses                      only for I4XM01  Control pulses <sub>Output</sub> = 1/(n+1) * Control pulses <sub>Input</sub> 0 : 1/(0+1)=1 1: 1/(1+1)= 1/2 2: 1/(2+1) =1/3 3: 1/(3+1)=1/4 4: 1/(4+1)=1/5 5: 1/(5+1)=1/6	n=0
<b>P51</b>	Pulse width: (n+1)*100 ns                      only for I4XM01  n: 0....255  e.g. n=19: (19+1)*100 ns=2000 ns= 2µs -> F <sub>max</sub> =1/(2*2 µs)=250 kHz	n=19

No.	Meaning	Default
<b>P52</b>	Internally used for trigger position.	
<b>P53</b>	Power stage monitoring 0 = off 1 = on	1
<b>P54</b>	Motor temperature in 1/10 °C -999999: Temperature module not existent -9999: negative overflow or temperature lower -220 °C at PT100 9999: positive overflow or temperature higher +390 °C at PT100	-999999 (read only)
<b>P55</b>	Motor temperature <b>warning</b> in 1/10 °C If the motor warmed up to a defined temperature value, a warning occurs. We recommend to operate the motor until it is cooled again.	0
<b>P56</b>	Motor temperature <b>shut-off</b> in 1/10 °C If the motor warmed up to a defined temperature value, the controller switches off and the power stage must be reset.	0
<b>P57</b>	Resolver voltage n=3...10 (Volt)	3
<b>P58</b>	Resolver ratio (ratio of primary to secondary winding) 0=1/8 1=1/4 2=1/2 3=1 4=2	2

## 10 Warranty, Disclaimer and Registered Trademarks

### 10.1 Disclaimer

---

Phytron GmbH has verified the contents of the manual to match with the hardware and software. However, errors and omissions are exempt and Phytron GmbH assumes no responsibility for complete compliance. The information contained in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

### 10.2 Warranty

---

The *phyMOTION*<sup>™</sup> modules are subject to **legal warranty**. Phytron will repair or exchange devices which show a failure due to defects in material or caused by the production process. This warranty does not include damage caused by the customer, for example, not intended use, unauthorised modifications, incorrect handling or wiring.

### 10.3 Registered Trademarks

---

In this manual several trademarks are used which are no longer explicitly marked as trademarks within the text. The lack of these signs may not be used to draw the conclusion that these products are free of rights of third parties. Some product names used herein are for instance.

- *phyMOTION*<sup>™</sup> is a trademark of the Phytron GmbH.
- *phyLOGIC*<sup>™</sup> is a trademark of the Phytron GmbH.
- Microsoft is a registered trade mark and WINDOWS<sup>®</sup> is a trade mark of the Microsoft Corporation in the USA and other countries.

## 11 Index

### A

Axes module 16, 18

Axis 21, 22

### C

Compensation for play 31

Configuration 10

Copyright 2

Counter 31

CPU 13, 15

### D

Download 11

### F

Firmware 11

ftp client 11

ftp server 11, 12

### G

GSD 10

### H

HW Config 10, 13

### I

I/O module 23, 24

### M

MCM 13

### P

Parameter 6

phyLOGIC™ 6

ProfiNet interface 9

### S

S7 station 9

Safety instructions 4

Scripts 11

Start-/Stop frequency 28

### W

Warranty 38